



There are two types of equipment. We are using **Type B** to ensure flatness after punching.

Type (A)

Punch holes from left side, then finally ends at right side. It will cause the right & left side bent easily.

Type (B)

Punch from top to end allows to release risk of bent and unflat.



